



## C4 Automatic Floor Shift Kit

To install this floor shift kit, you will need to notch the transfer case crossmember for clearance of the shifting cable. You will also need to make some minor modification to the cable mounting bracket. Please refer to the detailed images below for clarification on the process for these modifications.

